

# Northwest Territories

	VAPOUR INTRUSION SCREENING LEVELS ( $\mu\text{g}/\text{m}^3$ ) <sup>1, 2, 3, 4</sup>			
	Sub-Slab Residential	Sub-Slab Industrial/Commercial	Indoor Air Residential	Indoor Air Industrial/Commercial
<b>Benzene</b>	NC <sup>5</sup>	NC	NC	NC
<b>Tetrachloroethylene</b>	NC	NC	NC	NC
<b>Trichloroethylene</b>	NC	NC	NC	NC
<b>Vinyl Chloride</b>	NC	NC	NC	NC

## Notes:

1. The term "Vapour Intrusion Screening Levels" or "VISLs" is used as a generic term for regulatory standards.
2. Northwest Territories VISLs are not available. A link to request [Canada's Guidance for Soil Vapour Intrusion Assessment](#) publication is included for reference. This document was prepared to provide vapour intrusion guidance for federal departments.
3. For more information, refer to the [Environmental Guideline for Contaminated Site Remediation, November 2003](#).
4.  $\mu\text{g}/\text{m}^3$  = Micrograms per cubic meter
5. NC = No criterion.

Please see limitations of this document at [www.dragun.ca](http://www.dragun.ca).  
Last Updated: February 12, 2020.