

British Columbia

	VAPOUR INTRUSION SCREENING LEVELS ($\mu\text{g}/\text{m}^3$) ^{1, 2, 4}					
	Sub-Slab Residential	Sub-Slab Industrial/ Commercial	Indoor Air Residential	Indoor Air ³ Industrial/ Commercial	Soil Vapour Residential	Soil Vapour Industrial/ Commercial
Benzene	NC ⁵	NC	1.5	[10] 4	NC	NC
Tetrachloroethylene	NC	NC	40	[350] 100	NC	NC
Trichloroethylene	NC	NC	2.0	[20] 6	NC	NC
Vinyl Chloride	NC	NC	1.0	[10] 3.5	NC	NC

Notes:

1. The term "Vapour Intrusion Screening Levels" or "VISLs" is used as a generic term for regulatory standards. Available VISLs for British Columbia are noted in the table and can be found [here](#).
2. VISLs in brackets refer to Industrial Use Standards. VISLs without brackets in the Industrial/Commercial column refer to Commercial Use Standards.
3. Site-specific evaluation or mitigation is required if the VISLs are exceeded. Further British Columbia Ministry of Environment and Climate Change Strategy contaminated site remediation information is available [here](#).
4. $\mu\text{g}/\text{m}^3$ = Micrograms per cubic meter
5. NC = No criterion

Please see limitations of this document at www.dragun.ca.
Last Updated: April 2023