

Nunavut

| | VAPOUR INTRUSION SCREENING LEVELS ($\mu\text{g}/\text{m}^3$) ^{1, 2, 3, 4} | | | |
|----------------------------|--|--------------------------------|------------------------|----------------------------------|
| | Sub-Slab Residential | Sub-Slab Industrial/Commercial | Indoor Air Residential | Indoor Air Industrial/Commercial |
| Benzene | NC ⁵ | NC | NC | NC |
| Tetrachloroethylene | NC | NC | NC | NC |
| Trichloroethylene | NC | NC | NC | NC |
| Vinyl Chloride | NC | NC | NC | NC |

Notes:

1. The term "Vapour Intrusion Screening Levels" or "VISLs" is used as a generic term for regulatory standards.
2. Nunavut VISLs are not available. A link to request [Canada's Guidance for Soil Vapour Intrusion Assessment](#) publication is included for reference. This document was prepared to provide vapour intrusion guidance for federal departments.
3. For more information, refer to the [Nunavut Environmental Guideline for the Management of Contaminated Sites](#).
4. $\mu\text{g}/\text{m}^3$ = Micrograms per cubic meter
5. NC = No criterion.

Please see limitations of this document at www.dragun.ca.
Last Updated: January 11, 2018.