

# Ontario

	VAPOUR INTRUSION SCREENING LEVELS ( $\mu\text{g}/\text{m}^3$ ) <sup>1, 2, 3, 4</sup>			
	Soil Vapour Residential	Soil Vapour Industrial/Commercial	Indoor Air Residential	Indoor Air Industrial/Commercial
<b>Benzene</b>	253	[205,000] 76,000	0.506	1.63
<b>Tetrachloroethylene</b>	214	[181,000] 73,900	4.28	13.8
<b>Trichloroethylene</b>	13.6	[5,170] 2,020	0.271	0.401
<b>Vinyl Chloride</b>	6.32	[4,940] 1,680	0.126	0.406

## Notes:

1. The term "Vapour Intrusion Screening Levels" or "VISLs" is used as a generic term for regulatory standards. Site-specific evaluation or mitigation is required if the VISLs are exceeded.
2. Ontario province VISLs are noted in the table. These values can be found [here \(Human Health Tab and Soil Vapour Tier 2 Tab\)](#). Values in brackets are in reference to medium/fine textured soil. Indoor air values listed are the lowest risk level.
3. A link to request [Canada's Guidance for Soil Vapour Intrusion Assessment](#) publication is included for reference. This document was prepared to provide vapour intrusion guidance for federal departments.
4.  $\mu\text{g}/\text{m}^3$  = Micrograms per cubic meter

Please see limitations of this document at [www.dragun.ca](http://www.dragun.ca).  
Last Updated: February 12, 2020.