

Northwest Territories

	VAPOUR INTRUSION SCREENING LEVELS ($\mu\text{g}/\text{m}^3$) ^{1, 2, 3, 4}			
	Sub-Slab Residential	Sub-Slab Industrial/Commercial	Indoor Air Residential	Indoor Air Industrial/Commercial
Benzene	NC ⁵	NC	NC	NC
Tetrachloroethylene	NC	NC	NC	NC
Trichloroethylene	NC	NC	NC	NC
Vinyl Chloride	NC	NC	NC	NC

Notes:

1. The term “Vapour Intrusion Screening Levels” or “VISLs” is used as a generic term for regulatory standards.
2. Northwest Territories VISLs are not available. A link to request [Canada’s Guidance for Soil Vapour Intrusion Assessment](#) publication is included for reference. This document was prepared to provide vapour intrusion guidance for federal departments.
3. For more information, refer to the [Environmental Guideline for Contaminated Site Remediation, November 2003](#).
4. $\mu\text{g}/\text{m}^3$ = Micrograms per cubic meter
5. NC = No criterion