

Yukon

	VAPOUR INTRUSION SCREENING LEVELS ($\mu\text{g}/\text{m}^3$) ^{1, 2, 3, 4, 5}			
	Sub-Slab Residential	Sub-Slab Industrial/Commercial	Indoor Air Residential	Indoor Air Industrial/Commercial
Benzene	NC ⁶	NC	NC	NC
Tetrachloroethylene	NC	NC	NC	NC
Trichloroethylene	NC	NC	NC	NC
Vinyl Chloride	NC	NC	NC	NC

Notes:

1. The term “Vapour Intrusion Screening Levels” or “VISLs” is used as a generic term for regulatory standards.
2. The Yukon territory uses the "British Columbia Ministry of Environment, 1998. Protocol 2 for Contaminated Sites: Site-Specific Numerical Soil Standards" as one of the acceptable methods for determining site-specific numerical standards. More details on acceptable methods can be found [here](#).
3. A link to request [Canada’s Guidance for Soil Vapour Intrusion Assessment](#) publication is included for reference. This document was prepared to provide vapour intrusion guidance for federal departments.
4. For more information, refer to the Yukon Department of Environment "Managing a Contaminated Site" [webpage](#).
5. $\mu\text{g}/\text{m}^3$ = Micrograms per cubic meter
6. NC = No criterion

Please see limitations of this document at www.dragun.ca.
Last Updated: August 7, 2020