

Ontario

	VAPOUR INTRUSION SCREENING LEVELS ($\mu\text{g}/\text{m}^3$) ^{1, 2, 3, 4}					
	Sub-Slab Residential	Sub-Slab Industrial/ Commercial	Indoor Air Residential	Indoor Air Industrial/ Commercial	Soil Vapour Residential	Soil Vapour Industrial/ Commercial
Benzene	NC ⁶	NC	0.506	1.63	253	[205,000] 76,000
Tetrachloroeth-	NC	NC	4.28	13.8	214	[181,000]
Trichloroeth-ylene	NC	NC	0.271	0.401	13.6	[5,170] 2,020
Vinyl Chloride	NC	NC	0.126	0.406	6.32	[4,940] 1,680

Notes:

1. The term “Vapour Intrusion Screening Levels” or “VISLs” is used as a generic term for regulatory standards. Site-specific evaluation or mitigation is required if the VISLs are exceeded.
2. Ontario province VISLs are noted in the table. These values can be found [here \(Human Health Tab and Soil Vapour Tier 2 Tab\)](#). Values in brackets are in reference to medium/fine textured soil. Indoor air values listed are the lowest risk level.
3. A link to request [Canada’s Guidance for Soil Vapour Intrusion Assessment](#) publication is included for reference. This document was prepared to provide vapour intrusion guidance for federal departments.
4. $\mu\text{g}/\text{m}^3$ = Micrograms per cubic meter

Please see limitations of this document at www.dragun.ca.
Last Updated: October 2024