

# Nunavut

	VAPOUR INTRUSION SCREENING LEVELS ( $\mu\text{g}/\text{m}^3$ ) <sup>1, 2, 3, 4</sup>					
	Sub-Slab Residential	Sub-Slab Industrial/ Commercial	Indoor Air Residential	Indoor Air Industrial/ Commercial	Soil Vapour Residential	Soil Vapour Industrial/ Commercial
<b>Benzene</b>	NC <sup>5</sup>	NC	NC	NC	NC	NC
<b>Tetrachloroethylene</b>	NC	NC	NC	NC	NC	NC
<b>Trichloroethylene</b>	NC	NC	NC	NC	NC	NC
<b>Vinyl Chloride</b>	NC	NC	NC	NC	NC	NC

Notes:

1. The term “Vapour Intrusion Screening Levels” or “VISLs” is used as a generic term for regulatory standards.
2. Nunavut VISLs are not available. A link to request [Canada’s Guidance for Soil Vapour Intrusion Assessment](#) publication is included for reference. This document was prepared to provide vapour intrusion guidance for federal departments.
3. For more information, refer to the [Nunavut Environmental Guideline for the Management of Contaminated Sites](#).
4.  $\mu\text{g}/\text{m}^3$  = Micrograms per cubic meter
5. NC = No criterion